


**REPLACEMENT PARTS LIST FOR
MODEL B30LP**

ITEM NO.	NO. REQ'D.	STOCK NO.	DESCRIPTION
1	1	E00333	Control Valve
2	1	E00365	Reflector Assembly
3	1	E01438	Light Duty Frame
4	1	E01440	Heater Frame Assembly
5	1	E02406	Plenum Assembly 5¼ x 20
6	1	E02455	Burner Assembly
7	1	E03363	Baffle
8	1	E04357	Reverberator
9	1	E04369	Expanded Metal Screen
10	1	E04409	Grid Replacement Kit
11	1	E04426	Grid Screen Assembly
12	1	E05351	Connector
13	1	E05354	Jamb Nut
14	1	E05456	Orifice—LP—#56
15	1	E09352	Thermocouple
16	1	E09367	Tip Switch
17	1	E09368	Tip Switch Clip
18	1	E09371	Junction Block Adapter Kit
19	1	E11695	Regulator—LP
20	1	E16665	Elbow—90° St.—¼" FP x ¼" MP
21	2	E12369	Gasket—Fibr.
22	1	E14524	Thermocouple Bracket Assembly
23	1	E16671	Hose—LP—¼" ID—¾" MP x ¼" FP
24	1	E59129	Boil Set



Parts Department:
502-781-9600
Technical Services:
800-323-5190

Note: When ordering spare parts always give Heater model no., stock no., serial no. and types of gas used.

2. When disassembling parts from heater for repair, carefully note orientation of parts, then reverse procedure when assembling.

DESA
INTERNATIONAL